



## GBCA SAFETY TOOLBOX TALK

### FLAMMABLE LIQUIDS ON THE JOB SITE

The flash point of a liquid is the temperature at which it gives off sufficient vapor to form an ignitable mixture with air, near the surface of the liquid, or within a container.

**Flammable Liquids** have a flash point below 100°F and a vapor pressure not exceeding 40 psi at 100°F. Common examples of these on job sites are gasoline, acetone, and turpentine.

**Combustible Liquids** have a flash point above 100°F. The combustible liquids seen on most construction sites are Class II Liquids, which have a flash point at or above 100°F and below 140°F (60°C). Examples are No. 1, 2 and 3 fuel oils, and kerosene.

These types of liquids are often improperly stored or labeled, so be careful!

#### **Fire Extinguishers must be present near flammable materials. Follow this checklist:**

- Distribute fire extinguishers properly around the worksite, free from obstructions, and with clear pathways to access them.
- Check that the correct type of extinguisher is present for the type of flammables nearby.
- Regularly inspect fire extinguishers.
- Ensure that all job site workers have been trained on how to use fire extinguishers.

#### **Safety Guidelines When Handling Flammable or Combustible Liquids:**

- Store and handle them in APPROVED and MARKED containers.
- Use safety cans when dispensing flammable and combustible liquids
- A written identification label indicating the containers specific content must be present on all containers. Red cans are not gas cans unless they read GAS on them.
- Flammable liquid containers/cans must have a flash arresting screen. This prevents the liquid inside the can from combusting if exposed to fire. The flash arresting screen extinguishes the fire before it can reach the fuel.
- NEVER smoke, use spark-producing equipment, or use flame around these liquids.
- Do not fill running machinery with fuel. Turn off the engine.
- Post “NO SMOKING” signs as required near flammable materials storage areas.
- Fuel gas cylinders and oxygen cylinders must be separated by a minimum distance of 20 feet, or with fire resistant barriers. Keep oily rags away from these cylinders.
- Fuel storage tanks must be guarded to prevent damage from vehicular traffic.



# GBCA SAFETY TOOLBOX TALK ■ SIGN-IN SHEET

TOOLBOX TALK TOPIC:

EMPLOYER: \_\_\_\_\_ PROJECT: \_\_\_\_\_

PRESENTER: \_\_\_\_\_ DATE: \_\_\_\_\_

NAME (PRINTED)	SIGNATURE	COMPANY (IF APPLICABLE)
1. _____	_____	_____
2. _____	_____	_____
3. _____	_____	_____
4. _____	_____	_____
5. _____	_____	_____
6. _____	_____	_____
7. _____	_____	_____
8. _____	_____	_____
9. _____	_____	_____
10. _____	_____	_____
11. _____	_____	_____
12. _____	_____	_____
13. _____	_____	_____
14. _____	_____	_____
15. _____	_____	_____
16. _____	_____	_____
17. _____	_____	_____
18. _____	_____	_____
19. _____	_____	_____
20. _____	_____	_____

NOTES AND QUESTIONS:

<p><b>PRESENTER SIGNATURE (TO VERIFY ABOVE INFO):</b></p>  
---